

Operating Instructions Spartan Series BASC MODE

SARGENT AND GREENLEAF"



To Open

The factory code is 1 2 3 4 5 6. Enter 1 2 3 4 5 6

Each number is accompanied by a BEEP.

2 beeps at end of entry signifies number accepted. On a successful number entry,-turn safe handle to open safe. Safe is now open.



To Lock

Close safe door and turn handle to close position. The lock will lock automatically. Lock will sound 2 beeps to confirm locking

ALWAYS LEAVE THE SAFE DOOR OPEN WHEN CHANGING AND CHECKING CODES!



To Change the Number

Enter 0 0 0 0 0 0

Enter existing number ($1\,2\,3\,4\,5\,6$) for new safe

Enter new number twice (e.g. 142536 + 142536)

2 beeps signifies number accepted.

Test new number

Note: The number returns to original if the change is unsuccessful.



Anti - Tamper

If 5 incorrect codes are entered in a row,

The lock will enter a 3 minute penalty period

During which it will not accept input.

Pressing a key during the penalty time extends the period a few seconds.

If your lock does not respond to key presses and the keypad's red LED blinks once every 10 seconds, the lock is in penalty time. Do not press any buttons for at least 3 minutes, then try your code again.

MSC SAFE CO.

Shop 2-3/227 Main Street, OSBORNE PARK, W.A. 6017 Phone: (08) 9344 1962 Fax: (02) 9207 1578 www.mscsafeco.com.au msc@mscsafeco.com.au





Pull TAB towards you to release battery

Sargent & Greenleaf Spartan Series.

Replacing the battery on the

BASIC entry pad

Pull the TAB at the base of the keypad towards you to release the battery.

Remove and replace the battery with a

9 volt ALKALINE battery. DURACELL

Insert the battery and pod and ensure it is firmly in place.

Fitting of an incorrect battery type may result in intermittent operational problems.

It is important the replacement battery has a long use by date for efficient operation.



MSC SAFE CO.

Shop 2-3/227 Main Street, OSBORNE PARK, W.A. 6017 Phone: (08) 9344 1962 Fax: (02) 9207 1578 www.mscsafeco.com.au msc@mscsafeco.com.au